

Denso Tape Repair Kit

Denso Tape Repair

Denso tape can be used on wet composite or plastic kayaks to seal a small split or hole. However, drying the area prior to application will greatly improve the adhesion of the product.

Caution

This repair can be easily damaged if scraped or caught; treat it with care, especially when launching, landing or rock-hopping.

- 1 If possible dry the area e.g. with J-cloth or hat.



- 2 Clean away and/or flatten down any protruding material.



- 3 Remove the repair patch from packet (do not remove the foil backing).



- 4 Place the patch on the damaged area. More than one patch may be needed?



- 5 Starting from the centre of the patch, use hands/thumbs to gently press the patch into place. This will force any air bubbles out to the edges.



- 6 Run a hard, rounded edge (compass base, knife sheath, etc.), across the patch, to apply pressure and seal it in place. Pay particular attention to the edges to ensure they are sealed and pressed down securely.



- 7 Leave silver foil backing on to protect the patch.